

# Woody's Dooly™ Runners for Cruise Control

<b>DA4-9975</b>	
Модель снегохода	Года выпуска
<b>Arctic Cat™</b>	
Bearcat WT/WT Turbo	2006-08
Bearcat (Composite)	2006-15
CFR 800/1000	2010-11
Crossfire	2006-11
F-5/6/8/1000/LXR/Sno-Pro/1100	2007-14
Fan 570/ FS LXR	2008-14
Firecats	2003-06
Jaguar Z1	2007-08
Lynx 2000 LT (F570)	2015-16
M series (All)	2005-16
Pantera	2015-16
Panther	2006-08
Sabercats	2004-06
Sno-Pro 500	2010-14
T 660 Turbo/ Touring/ Turbo Touring/ LE	2005-07
T Z1/ T500/ T570/ T Z1 LXR	2008-14
XF	2012-16
Z1-LXR/ TRurbo/ EXT/ Sno-Pro	2009-11
Z370/ 570/ LX	2007
ZR	2014-16
<b>Yamaha™</b>	
SR Viper	2014
SR Viper M-TX/ SR Viper X-TX LE	2015
SR Viper M-TX	2016

<b>DY4-6580</b>	
Модель снегохода	Года выпуска
<b>Yamaha™</b>	
Apex ER/GT/RTX/LTX/LTX GT/SE/XTX	2006-13
Attack/ Attack GT	2006-07
FX Nytro MTX 153/162	2014
Nytro/ Nitro ER/RTX/FX/XTX	2006-12
Nytro FX/RTX SE/MTX SE 153/ SE162	2008-11
Phazer 500/500 DLX/ GT/ FX/ RTX/ MTX	2001-13
Phazer Mtn Lite/ Phazer M-TX	2007-16
RS Vector/ ER/ Mtn/ Rage/ GT/ LTX	2005-13
RX-1/ ER/ Mtn/ Warrior	2003-06
SX Viper/ ER/ Mtn/ Venom/ ER	2002-06
Venture500/600/700/RS/GT/Lite/MP/TF	2001-13
VK Professional/ RS Viking Pro	2007-12
Vmax 500/600/700 Dlx/ ER	2001-03

<b>DS4-9350</b>	
Модель снегохода	Года выпуска
<b>BRP™</b>	
Expedition Sport (Blow Molded)	2005-06
Freestyle/ Session 300/ 550/ Back City	2006-08
Legend (Blow Molded)	2003-04
MXZ 380/ 550 Fan (Blow Molded)	2003-05
Skandic Sport (Blow Molded)	2003-04
Skandic Tundra Fan 300/ 800 (Molded)	2006-07
Skandic Tundra 300F (Blow Molded)	2008-09
Skandic Tundra 550F (Blow Molded)	2010-12
<b>Polaris™</b>	
340 LX/ 550LX (Blow Molded)	2007-08
340 Touring (Blow Molded)	2007
340/ 550 Transport/ Trail Touring	2008-09
Supersport (Blow Molded)	2007-08

<b>DS4-9500</b>	
Модель снегохода	Года выпуска
<b>BRP™</b>	
Expedition Sport/ SE/ LE 1200/ 600HO	2011
Expedition SE/ LE	2012-14
Freestyle Backcountry (Pilot Skis)	2009
GT (5.7-6.9 Pilot Skis)	2010-11
GSX (Pilot Skis)	2006-15
GTX (Pilot Skis)	2006-09
Legend Touring (Pilot Skis)	2008-09
Mach Z (Pilot Skis)	2006-07
MXZ (5.7-6.9 Pilot Skis) (except XRS ski)	2006-15
MXZ (5.7-6.9 Pilot Skis) (except TS ski)	2016
Renegade Sport/ X/XRS (except TS ski)	2010-16
Skandic Tundra LT 550F/ V800 (Pilot)	2008-09
Skandic Tundra LT/ Sport (Pilot)	2010-11
Summit (Pilot Skis)	2006-11

<b>DP4-1225</b>	
Модель снегохода	Года выпуска
<b>Polaris™</b>	
500 XI SPA (1 per ski)	2007
600 Indy	2014-16
All composite (except Sidehiller2 and Accutrak2 skis)	1997-06
All Steel	1990-06
All IQ Chassis sleds (1 per ski)	2005-13
Rush (1 per ski)	2010-12
Trail RMK (1 per ski)	2007-10
Trail Touring	2010